

BAREVNICE •
COLOUR CARD •

z a p í n á m e c e l ý s v ě t



- SNÍMATELNÉ KNOFLÍKY DRESSING COLOR
- DETACHABLE BUTTONS DRESSING COLOR


AA 1950



AK 1969



BF 1930



CT 1932




DB 1910



DE 1975




AX 1972




GP 1991




HL 1945



LP 1948



MI 1981



ZZ 1959

